AS9006 Complete the pedestal test before fitting covers - prepared reference

Applicability

AS9006 assembly using the documented AMS1014/UP6 controller family. The archived original has an unpublished-rights notice; the public reference is an independently prepared summary.

Complete the pedestal test before fitting covers

The AMS1014/UP6 reference distinguishes the primary pedestal, connected secondary equipment and optional alarm or counting accessories. Verify which accessories are installed before enabling their functions in the service configurator.

After the wiring and alarm-volume setup, test the actual tagged passage and any connected remote alarm before closing the cable and base covers. Keep the optional counting connection separate from the basic tag-detection acceptance test.

UP6 controller options and testing

For the documented UP6 configuration, a primary pedestal can connect a secondary pedestal and auxiliary receivers. Optional people-counting and remote-alarm interfaces require the corresponding accessories.

Use the matching service configurator and verify the installed detection and alarm operation before fitting covers. Keep the power and interconnect wiring consistent with the supplied technical guide.

Before handover

- Identify the controller and revision before applying a menu or wiring reference.

- Test the actual tags with normal store equipment operating, then retain the accepted settings.

Document information

This is an independently prepared English reference based on the reviewed technical material. It is not a manufacturer-issued original, does not replace the delivered hardware instructions and does not add a manufacturer warranty or certification.